


For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
 (White) (Biscuit) (Stainless Steel) (Almond) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS


For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			9		Cover, Light	18		Cap, Vent
1		Cooktop, Ceran		9751327	White		9751271GW	White Mdl.
	9752625CW	White		9751633	Almond		9751271GT	Almond Mdl.
	9752625CT	Almond		9751632	Black		9751271GB	Black Mdl.
	9752625CB	Black		9753320	Biscuit		9751271GC	Biscuit
	9752625CC	Biscuit	10		Backsplash	19	9751366	Cap, Vent
2	9780939	Gasket, Cooktop		9751266GB	Black	20	9751984	Fuse, Bi-Metal
3		Trim, Cooktop (Right Hand)		9751266GW	White	21		Cap, Large (2)
	9751275PT	Almond		9751266GT	Almond		3188974	Gray
	9751275PW	White		9751266GC	Biscuit		3185793	Black
	9751275PB	Black		9780265	Screw (5)		9752666GM	Moleskin
	9751275PC	Biscuit (Left Hand)	11		Bezel, Small LR-RF	22	9752006	Thermostat, Fixed
	9751276PT	Almond		9752624GS	Gray	23	9752034	Seal, Rubber (2)
	9751276PW	White		9752624GB	Black	24	9750273	Receptacle, Lamp
	9751276PB	Black		9752624GM	Moleskin	25	422581	Lamp, Fluorescent
	9751276PC	Biscuit	12		Bezel, Large RR-LF	26	9751664	Cover, Backsplash
4		Gasket, Cooktop		9752623GS	Gray		3149333	Screw (5)
	9781616	Black		9752623GB	Black			#10AB x 3/8
	9781615	Almond		9752623GM	Moleskin	27		Endcap, Backsplash (Right Hand)
5	9752632	Support, Element	13		Grate, 2 Burner		9751268FB	Black
6	9751629	Bracket, Pivot		9753219CS	Gray		9751268FW	White
	9780265	Screw, (2)		9753219CB	Black		9751268FT	Almond
7	9750866	Holder, Starter		9753219CM	Moleskin		9751268FC	Biscuit (Left Hand)
8	9750821	Support Clips (4)	15	9752638	Pad, Grate (4)		9751267FB	Black
	9751871	Screw (4)	16		Cap, Small (2)		9751267FW	White
				3188975	Gray		9751267FT	Almond
				3185796	Black		9751267FC	Biscuit
				9752667GM	Moleskin			Glass, Backsplash
			17	341196	Thermo-Disc	28	9781154	White
				9780265	Screw, (2)		9753292	Stainless Steel
						29	9781118	Starter, Light
						30	9753291	Panel, Backguard (Stainless)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)




Illus. No.	Part No.	DESCRIPTION
1		Burner, Surface
	9752641	Small RF-LR
	9752640	Large LF-RR
2	9752649	Tubing, Burner(RF)
3	9752650	Tubing, Burner(RR)
4	9752647	Tubing, Burner(LF)
5	9752648	Tubing, Burner(LR)
6	9752646	Tubing, Manifold (Left)
7		Valve, Burner
	9751333	Small (2)
8		Valve, Burner
	9751334	Large (2)
	3185829	Bolt, Gas Valve(4)
9	9751325	Switch, Ignitor(4)
10	9751285	Tubing, Manifold (Right)
11	9751287	Manifold (2)
12	9751283	Tee, Flare
13	3185804	Electrode
	3185805	Speed nut
16	3185947	Orifice, Small #56
	3185948	Orifice, Large #52
18	9751854	Tubing, Flex
19	9781457	Bracket, Manifold
20	9752627	Bracket, Burner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	Console, Glass
9751888	White Mdl.
9751894	Black Mdl.
9751892	Almond Mdl.
9753407	Biscuit MDL.
9751895	Stn. Steel MDL
2	3191106 Timer, Electronic
9780271	Screw, (2)
4	End Cap
	Right Hand
9751280FW	White
9751280FT	Almond
9751280FB	Black
9751280FC	Biscuit
	Left Hand
9751279FW	White
9751279FT	Almond
9751279FB	Black
9751279FC	Biscuit
9780265	Screw, (2)
	10 x 3/8
8	Knobs, Control
9751199FW	White Mdl.
9751199FT	Almond Mdl.
9751199FF	Black Mdl.
9751199FC	Biscuit
23	Washer, Console (4)
9751450	White Mdl.
9751451	Almond Mdl.
9751449	Black Mdl.
9753321	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2		Trim, Door-Left	6		Vent, Door	20	9780583	Drawer & Roller
	9750631PW	White		9753498GW	White		9750257	For Stn. Steel MDL
	9750631PT	Almond		9753498GB	Black	21	9750169	Bracket, Drawer
	9750631PB	Black		9753498GT	Almond	22	423713	Support, Roller
	9750631PC	Biscuit		9753498GC	Biscuit	23	9750676	Retainer, Door
3		Trim, Door-Right		9781490	Seal, Door	24		Front, Drawer
	9750632PW	White		9781659	Gasket, Vent		9750168PW	White
	9750632PT	Almond	8		Handle, Door		9750168PT	Almond
	9750632PB	Black		9780523PW	White		9750168PB	Black
	9750632PC	Biscuit		9780523PT	Almond		9750168PC	Biscuit
4		Trim, Door Bottom		9780523PB	Black		9750569PB	For STN.Steel MDL
	9781209PW	White		9780523PC	Biscuit	25	9750693	Heat Channel
	9781209PT	Almond	9	9781449	Gasket, Door Glass	27	90296	Clip
	9781209PB	Black	10	9750234	Hinge, Door R or L	28	9781502	Retainer, Glass
	9781209PC	Biscuit	11	9781592	Baffle, Glass	29	9780265	Screw
5		Glass, Door	12	9781602	Frame, Window	30	9780272	Screw
	9781627PW	White	13	9781586	Shield Door	31	9781072	Screw
	9781627PT	Almond	14	9780771	Bumper, Rubber	33	9781771	Steam Deflector
	9781627PB	Black	15	9781593	Glass, Door (2)	34	9750614PB	Trim, Drawer-Top
	9781627PC	Biscuit	16	9781587	Seal, Glass	35	9753329	Spacer
	9753378	Stainless	18	9781626	Insulation	36	9753293	Panel, Drawer (Stainless)
			19	9781600GM	Liner, Door	37	9750613PB	Trim, Drawer-Btm

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			9	9751789	Fan Duct, Side	16	9751020	Motor, Fan
				9780265	Screw, (4)		9751808	Screw, (3) #8 x 1"
			11	9752637	Burner Box	17	9750147	Bottom Rail (2)
				9780269	Screw, #8-32 x 3/8		9780265	Screw, (8) 10 x 3/8
1	4454392	Module, Spark		9780265	Screw (8) 10 x 3/8	18	312701	Foot, (4)
	9780269	Screw		9780275	Screw, (2) 8 x 3/8	19	9750149	Hinge, Door L or R
	98997	Clip					9780265	Screw, (2) 10 x 3/8
2	9750514GM	Chassis, Front	12	9752735	Retainer, Insulation		9780270	Screw, (2) 8 x 3/8
5	9753339GM	Oven Liner				20	421771	Support Rail, Pan
6	3191649	Gasket Oven		9780265	Screw (9) 10 x 3/8		9780265	Screw, (2) 10 x 3/8
7		Oven, Side L or R	13	9751653	Duct, Top	21	9781025	Shield, Drawer
	9750148PW	White		9780265	Screw, (2)		9780265	Screw, 10 x 3/8
	9750148PT	Almond	14	9751060	Support, Fan	22	9751641	Plate, Reflectance
	9750148PB	Black	15	9750223	Drawer Rail, Left 10 x 3/8		9780265	Screw, 10 x 3/8
	9750148PC	Biscuit				25	9751592	Vent Tube
	9780265	Screw (4) 10 x 3/8		9750224	Drawer Rail, Right		9780265	Screw, 10 x 3/8
8	9780664	Shield, Insulation		9780265	Screw (2) 10 X 3/8	29	9781581	Door Switch
	9780265	Screw (2)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


BROILER & OVEN BURNER PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)

Illus. Part
No. No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.


- | | | |
|----|-----------|--------------------|
| 1 | 9752737 | Shield, Oven (2) |
| 2 | 9752738 | Flame Shield, Bake |
| | 9751643 | Screw, 10-3/8 (2) |
| 3 | 9752922 | Burner, Broiler |
| | 9751644 | Screw, 10-24x1/2 |
| 4 | 9751367 | Burner, Bake |
| 6 | 9753108 | Ignitor, |
| | 9781509 | Screw |
| | 9751643 | Screw, 10-24x3/8 |
| 7 | 9752858 | Bracket, |
| | | Broil Shooter |
| | 9780265 | Screw, 10 x 3/8 |
| 8 | 9752736GM | Pan, Oven Bottom |
| 9 | 9751173 | Tubing, Broil |
| 10 | 9752698 | Valve & Regulator |
| | | Assembly |
| | 776593 | Screw, 1/4-20x1/2 |
| 12 | 9781015 | Tubing, Valve |
| | | To Regulator |
| 13 | 9752734 | Pan Support, Bake |
| 14 | 9751600 | Bracket, Bake |
| | 9751643 | Screw, 10-24x3/8 |
| 15 | 9751203 | Nut #18 5/8 |
| 16 | 9752920 | Coverbox |
| | | (Broiler Tubing) |
| | 9780265 | Screw |
| 17 | 9752716 | Orifice #54 |



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	9781543	Assembly, Fan
	9780272	Screw, #10 x 1/2
9	9751904GM	Baffle, Convection
	9780270	Screw, (2) 8 x 3/8

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

10	4167277	Lock-Nut, Cvr.Jack
11	4167266	Jack Cover
12	305289	Gasket
13	4173575	Receptacle, Probe
14	3179672	Spacer, Tubing
15	8935	Bulb, Oven
16	9781050	Light, Socket
17	3150144	Probe
18	420104GM	Grill, Broiler


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

19	420101GM	Pan, Broiler
20	9750827	Rack, Roasting
21	9750823	Rack, Standard (3)
22	3148440	Sensor
	9781509	Screw 8-32 x 3/8
23	9781049	Lens, Light
24	3184533	Gasket, Lens

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REAR CHASSIS PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	9751051	Back, Chassis
	340184	Screw (2)
3	9751353	Panel, Rear Cover
	423247	Screw (3)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

5	9751418	Bracket, Lock
	9780265	Screw (2)
6	9751500	Bracket, Regulator Valve
7	9751439	Oven Lock Assy.
	9780265	Screw (2)
8	9751590	Solenoid
	422222	Screw
	424238	Washer

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

12	9751763	Switch, Interlock
	9750887	Screw (2)
	9750888	Nut (2)
15	9750523	Rod, Lock
16	9780881	Ballast, Lamp
	9780265	Screw (2)
17	258076	Block, Terminal
	98884	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: KGRT507GWH0, KGRT507GBT0, KGRT507GBS0, KGRT507GAL0, KGRT507GBL0
(White) (Biscuit) (Stainless Steel) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150°c
242820	Wire, Black	14 Ga. 150°c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242829	Wire, Red	12 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242826	Wire, White	14 Ga. 150°c
242827	Wire, Yellow	14 Ga. 150°c
242832	Wire, Yellow	14 Ga. 200°c

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
72109	New Avocado
72108	Coffee
72110	Harvest Gold
72112	Toast
72113	Platinum
511873	White Porcelain (2 Oz.)
4392899	Biscuit

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
261888	New Avocado
261886	Coffee
261890	Harvest Gold
285365	Toast
285366	Platinum
285006	Superior Black
206922	Primer (White)
4392901	Biscuit

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
261891	Harvest Gold (Uncut)
285367	Toast (Uncut)
285368	Platinum (Uncut)
4392900	Biscuit (Uncut)

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean (1/2 Pt.)

INSULATION

9751164	Insulation, Wrap
9750221	Insulation, Rear
9751323	Insulation, Bottom

CLEANER, COOKTOP

3184477	Glass Cleaner
3183488	Scraper

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORIES

241430	Foil, Aluminum Oven (18" X 25')
--------	---------------------------------

CONVERSION KIT

	Gas Conversion Kit
9751844	LP
9752717	Natural

LUBRICANT

261582	Grease
--------	--------

ANTI-TIP KIT

9751745	Anti-Tip Kit
---------	--------------

LITERATURE PARTS

LIT9752397	Installation Instructions
LIT4449066	Convection Cookbook
LIT9753310	Use & Care Guide
LIT9752686	Smart & Easy Guide
LIT9752669	Tech Sheet
LIT9752969	Wiring Diagram
LIT9752775	Anti-Tip Template
LIT3191638	Safer Cooking Tips

WIRING HARNESS PARTS

9781641	Harness, Wire (Main Harness)
9751708	Harness, Wire (Neutral Gas)
3190208	Harness, Wire (Spark Control)
9750376	Harness, Wire (Oven Door)
9751750	Harness, Wire (Flourescent)
9752769	Harness, Wire (Spark Module)
9752770	Jumper, Burner (4)
20082084	Tie, Wire
9751868	Grommet Harness (2)
3196520	Clip, Wire
9781055	Power Cord